




INSTALLATION INSTRUCTIONS
FLOWER LEANBACK STOOL
PYSTL



INTENTIONALLY LEFT BLANK

1 SPECIFICATIONS

REFERENCE		STANDARD	LOOSE FILL
HEIGHT TO TOP OF SEAT (H1)	m	0.46	
HEIGHT TO BOTTOM OF SEAT (H2)	m	0.28	
LENGTH (L)	m	0.31	
WIDTH (W)	m	0.31	
WEIGHT	kg	5.3	8.4
HEAVIEST PART	kg	3.45	
LARGEST PART L x W x H	m	0.70 x 0.15 x 0.15	
CONCRETE	m ³	0.03	
MAN-HOURS	hr	0.5	0.5
MANPOWER		1	1
CONSTRUCTIONAL SPACE	m	1 x 1	1 x 1

NOTE: All dimensions in metres.


Concrete mix is recommended at:
 1 part cement;
 2 parts sand;
 4 parts aggregate;
 by volume with 20mm aggregate
 (20 N/mm² min compressive strength)

Constructional Space (shown in the above table) is the approximate working area required to lay out and assemble the equipment.


This furniture product for young children has been designed for use in seating, picnic and park areas. If positioned amongst playground apparatus consideration should be given to providing an impact attenuating surface as the product may be used by children in a manner not intended for a piece of furniture.

Tools: Plumbline, 1m tape measure, Spirit level, M10 Torx tool (supplied with unit), Torque wrench. Loose fill only:
 Masking tape.

Minimum Personal Protective Equipment:- Gloves, Armored boots & Protective goggles.





NOTE: Generally, it is recommended that loose fill surfaces are installed to a depth of 300mm. However with certain loose fill materials, a greater depth may be required. This will need to be determined by allowing 100mm for dispersal in addition to the thickness required to achieve the required critical fall height.



CONCRETE SPECIFICATIONS	
BLOCK	L x W x Depth
A	0.30x0.30x0.35

2 PARTS LIST

ITEM	CODE	DESCRIPTION	QTY.	WEIGHT (kg)
1.1	86810041	POST	1	3.60
1.2	86800041	TOP	1	1.60
1.3	10931000	TEE NUT-M10	3	0.04
1.4	10121020	RESISTORX BOLT M10x20	3	0.02
1.5	10291000	WASHER M10	3	0.002
LOOSE FILL				
1.6	EPLUG	GROUTING IN LUG	1	3.000



3 ASSY & INSTALLATION PROCEDURE.

- i) Before commencing installation the surrounding area must be sufficiently fenced and signs erected to warn the public of the risk of injury.
- ii) Secure the top (item 2) to the post (item 1) using 3-off M10 tee-nuts (items 3), M10 Resistorx bolts (items 4) and washers (items 5).
- iii) Tighten to 20-25Nm.
- iv) Mark out foundation and excavate hole.(refer to site plan for unit location)
- v) Move stool assy into excavation, pack up to height required, level and plumb.
- vi) Fill hole with concrete to required level, taking into account any surfacing requirements. Ensure full volume of concrete is used. The top should slope down & outwards locally from the equipment upstand to the required level to form a water shed.
- vii) Keep installation off limits to the public until, concrete has completely cured. (Recommended initial curing time 48hrs).

4 POST INSTALLATION INSPECTION

CHECK

- 1 All fixings are tightened and have no protruding sharp edges.
- 2 Paint work and polyethylene are not damaged.
- 3 Concrete foundations are secure.
- 4 Concrete has a water shed away from support column.
- 5 Site is clear of all tools and rubbish.
- 6 Remove any warning signs.

CHECK