




**INSTALLATION INSTRUCTIONS**


**NEXUS WHIZZER**







**NXWZS - NXWZE**






NO PART OF THIS MANUAL OR DOCUMENT MAY BE COPIED OR RE-PRODUCED IN ANY FORM OR BY ANY MEANS WITH OUT THE EXPRESS WRITTEN PERMISSION OF SMP (PLAYGROUNDS) LTD.











email: [sales@smp.co.uk](mailto:sales@smp.co.uk)  
[www.smp.co.uk](http://www.smp.co.uk)






						
	LxWxH (m)	kg	m <sup>3</sup>	m	≥EN1176	x 1= T
<b>NXWZ*</b>	0.39 x 0.48 x 1.55	48.00	0.42	3.00 x 3.00	0.30m	T=4h




# 1 PARTS LIST

ITEM	REF		NXWZS	NXWZE	kg
1	38004051		1		16.000
2	38004000		1		31.000
3	38004031		2		0.500
4	SSGIL			1	2.200
5	10251230	 M12 X 30	4		0.050
6	10121020	 M10 X 20	6		0.020
7	10291200	 M12 13X24X2.5	4		0.003
8	10291000	 M10 11X21X1	6		0.002
9	10301200	 M12 13X20X1	12		0.002
10	10931000	 M10	6		0.020




ITEM	REF		NXWZS	NXWZE	kg
11	19028651			4	0.002
12	10121000	 T45 M10		2	-




# STEP 1




# STEP 2


S2 (50mm) ≥C20-25
 7 x 24h
 101


**STEP 3**




**STEP 4**








**STEP 5**










**Appendix A:**



**REF 38004000**

ITEM	REF		QTY.	kg
A1	71000102		1	20.000
A2	38004001		1	11.000
A3	71000109		1	0.080
A4	10121030	 M10 X 30	1	0.030
A5	10309999	 M10 11X30X2.5	2	0.011




**REF 38004001**


ITEM	REF	DESCRIPTION	QTY.	kg
A2.1	38004012		1	10.100
A2.2	71022208		1	0.60
A2.3	71022210		1	0.70
A2.4	71000110		1	0.015




Appendix B:




LOOSEFILL

TYPE 1/2  144




GRASSMATT

TYPE 5  144



WETPOUR

TYPE 3  144



TILES

TYPE 3  144

SMP Playgrounds Ltd recommends an effective *Impact Absorbing Surface tested to EN1177 & BS7188* beneath this play equipment. Refer to manufacturers instructions for details of installation. The surface should have a Critical Fall Height greater than the Maximum Freefall Height of the equipment. Subject to a risk assessment & for certain Fall Heights a grass surface may be used.

Constructional Space is the approximate working area required to lay out and assemble the equipment.

Care should be taken when siting this equipment in order to discourage users in the surrounding area from unintentionally coming into contact with the equipment. This can be achieved, for example by placing the equipment at the perimeter of the play area.

For the safe operation of this equipment it must be installed on horizontal ground with the required minimum space.

If a loose fill surface is selected for this item it will require a very high level of maintenance to ensure a sufficient thickness is in place at all times to provide 'critical fall height' protection.

The concrete foundations indicated are for average ground. Care should be taken concerning abnormal conditions.

**Tools:** 5m tape measure, Spirit level, M10 Torx tool (Supplied with unit), 19mm A/F Socket, Extension bar, Torque wrench.

## 1 INSTALLATION & ASSY PROCEDURES

### 1.1 SAFE WORKING PRACTICE:

A full risk assessment should be carried out prior to commencing the installation, which will be specific to the site selected. The major risks associated with purely the assembly of this product are highlighted below, which can form part of this overall assessment.

### 1.2 RISKS:

- i) Large parts which could be difficult to lift or handle.

### 1.3 CONTROL MEASURES:

- i) All staff working on installation to wear suitable Toe Protective Shoes and Gloves.
- ii) Any staff or other persons on site, not working directly on the installation, to be kept away from the installation.
- iii) Care should be taken when any awkward/heavy lifting may be required.

### Pre Installation Inspection:-

- i) Inspect all parts for damage (that may have occurred during transportation & storage). Finish Coatings, if found to be damaged these should be made good before erection (Refer to maintenance instructions). Any damaged or missing parts must be replaced.
- ii) Warn the public of the risk of injury, by placing signs and fencing the surrounding area, before commencing installation.

### 1.4 INSTALLATION

- i) Refer to site layout for position and orientation of product, then, mark the outline of the position of the footings with e.g. spray or chalk etc. Excavate the hole.
- ii) Position Shaft & Bearing Assembly (item 2) into excavation, pack up to height, level and plumb. **(STEP 1)**.
- iii) Shim and brace Shaft & Bearing Assembly into position.

Concrete mix is recommended at:  
 1 part cement;  
 2 parts sand;  
 4 parts aggregate;  
 by volume with 20mm aggregate  
 (20 N/mm<sup>2</sup> min compressive strength)

- iv) Fill the hole with concrete to the required level, taking into account any Impact Absorbing Surfacing requirements. Ensure that the full volume of concrete is used. The top of the concrete should gradually (1:100) slope down & outwards locally from the equipment postulant to the required level to form a watershed. **(STEP 2)**
- v) Keep installation off limits to the public until the concrete has completely cured. (Recommended initial curing time is 48 hours).
- vi) Place the Whizzer Pole Assembly (item 1) onto the Shaft & Bearing Assy (item 2). Secure the Whizzer Pole Assembly to the Shaft & Bearing Assy using 4-off M12 x 30 Hex Head Bolts (item 5) and M12 Washers (item 7). Fully tighten to 50-60 Nm. **(STEP 3).**
- vii) Fit 3 off Tee Nut (item 10) and Shakeproof Washer (item 9) into each Eko Grip Platform (item 3). **(STEP 4).**
- viii) Locate each Eko Grip Platform (item 3) into position on the Whizzer Pole Assembly plate (item 1) and secure into place with 3 off M10 x 20 Resistorx Bolts (item 6) and M10 Washers (item 8) and Shakeproof Washers (item 9) and fully tighten.
- ix) Fit Plastic Cap (item 11) into holes in Eko Grip Platform (item 3) to cover heads of Hex Head Bolts (item 5). Ensure they fit flush with the surrounding plastic surface with no sharp edges. **(STEP 5).**

## 2 POST INSTALLATION INSPECTION

CHECK	CHECK	✓
1 The unit is installed at the correct height.	<input type="checkbox"/>	
2 All fixings are tightened to the correct torque and have no protruding sharp edges.	<input type="checkbox"/>	
3 Paint work is not damaged.	<input type="checkbox"/>	
4 The Eko Grip Platform is not damaged.	<input type="checkbox"/>	
5 The Whizzer rotates freely.	<input type="checkbox"/>	
6 Concrete foundations are secure.	<input type="checkbox"/>	
7 Adequate provision of Impact Absorbing Surfacing with no obstructions or other hazards within the equipments minimum space.	<input type="checkbox"/>	
8 Site is clear of all tools and rubbish.	<input type="checkbox"/>	
9 Remove any warning signs.	<input type="checkbox"/>	